


05

WHAT TO MEASURE

Verify Measurements


*These four measurements determine whether hardware will fit.
Confirm before ordering — especially on replacements.*



Door Thickness

Measured from face to face.


Standard: $1\frac{3}{8}$ " interior • $1\frac{3}{4}$ " exterior



Backset

Measured from edge to bore center.

Common: $2\frac{3}{8}$ " • $2\frac{3}{4}$ "




Door Handing

Stand outside the room facing the door.

Hinges left = LH

Hinges right = RH.



Door Swing

Stand outside the room facing the door.

Door swings toward you = outswing.

Away from you = inswing.